

## For Immediate Release

**Press Contact** Doug McClure  
MarCom Manager  
858-536-5052  
[dmcclure@focalspot.com](mailto:dmcclure@focalspot.com)

**Note to Editors:** Supporting product photos (300dpi / knocked out / PSD) and MS Word text files may be downloaded from the FocalSpot website, URL:  
<http://www.focalspot.com/pr.htm>

### **New X-Y Table for DEN-ON RD-500 Series Semi-Automated BGA/SMT Rework Stations**

**San Diego, California (August 3, 2007)** – FocalSpot, Inc ([www.focalspot.com](http://www.focalspot.com)), a premiere provider of affordable high-quality BGA/SMT inspection and rework solutions to the electronics manufacturing industry, today announced the introduction of a new and improved FocalSpot designed X-Y Table for DEN-ON RD-500 Series BGA/SMT Semi-Automated Rework Stations.

FocalSpot designed the new X-Y Table to provide rigid support and holding flexibility for large highly-populated PCBs commonly found in computer networking infrastructure products.

The table design is flexible enough to accommodate unlimited underside support configurations. The clamps are small enough to fit between connectors and plugs without the need for additional tooling.

The new table design offers independently adjustable four-sided "picture frame" clamping for improved lateral support of PCB's. Six (6) under-board supports can be positioned to provide localized support as needed. All clamps can be locked in place allowing the PCB to remain fully supported and move as one-piece. The fixturing reduces board sag and warpage by over 4.5X; which is critical for lead-free applications.

#### **About FocalSpot, Inc.**

FocalSpot, Inc. is recognized worldwide as a leader in the design and manufacture of affordable high-quality x-ray inspection systems. FocalSpot also sells, reconditions and supports pre-owned Nicolet X-Ray Inspection systems (with 18 years experience); providing ongoing service, parts, installation and training worldwide.

FocalSpot is a regional distributor and value-added reseller for DEN-ON advanced semi-automated BGA/SMT rework solutions; and Optilia BGA/SMT video microscopes; providing sales, service and support in North/South America, Canada and Mexico.

For more information, visit [www.focalspot.com](http://www.focalspot.com), email [sales@focalspot.com](mailto:sales@focalspot.com), or call (858) 536.5050.